

STEP-BY-STEP GUIDE TO MEASURING FOR ROBE DOORS

YOU WILL NEED

1. Measuring Tape
2. Notepad or Paper
3. Pencil or Pen

MEASURING WIDTH

A. Bottom Width:

- At the bottom of the wardrobe opening
- Measure across from the inside of one side to the inside of the opposite side
- Record this as the bottom width (as shown in measurement A on the diagram)

B. Top Width:

- Repeat the process at the top of the wardrobe
- Measure across from the inside of one side to the inside of the opposite side
- Record this as the top width (as shown in measurement B on the diagram)
- Note: Use a ladder if needed for accurate top measurements

MEASURING HEIGHT

C. Left Side Height:

- On the left-hand side
- Measure from the bottom to the top of the wardrobe opening
- Record this as the left side height (as shown in measurement C on the diagram)
- Note: Use a ladder if needed for accurate measurements

D. Right Side Height:

- Repeat the process on the right-hand side
- Measure from the bottom to the top of the wardrobe opening
- Record this as the right side height (as shown in measurement D on the diagram)
- Note: Use a ladder if needed for accurate measurements

OPTIONAL: CHECK FLOOR LEVELS

Floor Level Check:

- Use a level to check if the floor is even
- If the floor is uneven by more than 10mm, consider installing a level floor batten to ensure smooth operation of the robe doors

Following these steps will help ensure accurate measurements for robe doors, allowing for proper fitting and smooth functionality.

DIAGRAM OF ROBE DOOR OPENING

